

EWD-LG-SJ3 {
-A
-B
-C
-D

EWD-RLG-SJ3 {
-A
-B
-D

User's Guide (V1.0)

XIAN EXCELLENT ELECTROMECHANICAL CO., LTD

Table of Contents

Product Overview	1、 Product Appearance and Type Nomination	Page 3
	2、 Installing Method and Working Principle	Page 5
	3、 Schematic Diagram of the Controller Appearance	Page 6
	4、 Schematic Diagram of the Sensor Appearance and Installing Method	Page 7
	A. Standard “Disc” type Intelligent Load Sensor	Page 8
B. Standard Character “王”type Intelligent Tension Sensor	Page 9	
C. Standard “Convex” type Intelligent Stress Sensor	Page 10	
D. Standard Character “—” type Intelligent Load Sensor	Page 11	
Installation & Adjustment	5、 Explanation of Terminals of the System Controller	Page 13
	6、 System Structure and Installation Schematic Diagram	Page 16
	7、 Install Method of Sensor and Controller	Page 17
	8、 System Adjustment and Explanation (Autotune)	Page 18
	①.Initialization: Selection of Compensating Method	Page 19
	②.Lock the Dead Weight of the Car	Page 20
	③.No Load Autotune Operation Mode	Page 20
	④.Rated Load Autotune Operation Mode	Page 21
Implication and Adjustment Method of the Operation Parameters	9、 Adjustment of the System Parameters	Page 22
	10、 Explanation of the Meaning of Parameter P	Page 23
Indicating Code Explanation	11、 Explanation of System Normal Operation Code	Page 28
	12、 Explanation of the Code of Other Operations and Fault	Page 28
How To Do?	13、 Brief Analysis of Other Status	Page 29
	14、 How to repeat the Autotune operation for the system?	Page 31
	15、 How to do Rated Load Autotune by adopting 20% rated load?	Page 32

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	16、How to do "Weight Setting" system Autotune for EWD-GA Sensor?	Page 32
	17、How to Obtain the Product Version Code?	Page 32
System	18、Main characteristics	Page 32
	19、Technical Specifications	Page 33
Characteristics		
Promise		Page 34
Others		Page 35
<i>Attached Drawings [1], [2], [3]</i>		Page 36、 37、 38

Caution: This system is applicable an elevator with **fixed car platform**. Before use, be sure to read the following sections carefully.





Note: Under any condition, our part is just responsible for the quality of product in the period of guarantee service.

Declaration: For the reason of technology advancement, our company reserves the right of improving product. As for the relevant technical parameters, Please refer to the technical handbook delivered with the product.

System Overview

1、 Product Appearance and Type Nomination:



1) Sensor of EWD-GA/ GB/ GC/ GD

Sensor Appearance				
	Notes:	<p>① For sensor in conjunction with EWD-GW1 transducer, a cable of 1 meter long is supplied with it</p> <p>② For directly connected sensor, default length of the cable</p>		

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

		supplied with it is 8 meters			
Product Naming	Ordering Type	EWD-GA	EWD-GB	EWD-GC	EWD-GD
	Sensor Type	“Disc” type Load Sensor	Character “王”type Tension Sensor	“Convex” type Stress Sensor	Character “—”type Load Sensor
	Detailed Explanation	See Fig. [3A]	See Fig. [3B]	See Fig. [3C]	See Fig. [3D]


2) Controller of EWD-LG-SJ3

Install at the rope hitch of car top	EWD-LG-SJ3				
Application Range	Be applied to elevator of 1:1 roping drive with the rope hitch at the car top. The sensor uses 2 wires of the car traveling cable for serial communication with the controller.				
Controller Appearance	 <p>See Fig.[2]for details</p>		 <p>When choosing controller of type EWD-LG-SJ3, it must be in conjunction with remote transducer of EWD-GW1</p>		
Product	Ordering Type	EWD-LG-SJ3A	EWD-LG-SJ3B	EWD-LG-SJ3C	EWD-LG-SJ3D

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Naming	Assorted Sensor	EWD-GA	EWD-GB	EWD-GC	EWD-GD
--------	------------------------	--------	--------	--------	--------

3) Controller of EWD-RLG-SJ3


Install at the rope hitch in machine-room	EWD-RLG-SJ3				
Application Range	Be applied to elevator of 2:1 roping drive with the rope hitch in machineroom. There is an 8-meter-long cable along with the sensor.				
Controller Appearance					
	See Fig.[2]for details				
Product Naming	Ordering Type	EWD-RLG-SJ3A	EWD-RLG-SJ3B	EWD-RLG-SJ3C	EWD-RLG-SJ3D
	Assorted Sensor	EWD-GA	EWD-GB	EWD-GC	EWD-GD

2、 Installing Method and Working Principle of “EWD-LG-SJ3/RLG-SJ3”

With the constantly development of elevator technology, the impact of elevator weighing device on elevator performance can not be neglected. The requirement of elevator for weighing devices with high accuracy, high reliability and multi functions becomes extremely urgent.

Presently, the progress of sensor technology and microcomputer is


ceaseless. With the adoption of highly accurate intelligent ”tension” or ”load” and “stress” sensors, the electric signal produced by elevator car load changing is tested and inspected. System sensor installed at the traction rope hitch: Type “EWD-LG-SJ3”: With the adoption of serial communication technology, the signal can be transmitted remotely, highly accurately without loss.; Type “EWD-RLG-SJ3”: There is an 8-meter-long signal transmitting cable with the sensor. And the single-chip built-in the controller may do scientific calculations fulfilling the aim of weighing the effective load in elevator car.



Take EWD-LG-SJ3 as example: system installing position: sensor EWD-RLG-SJ3 Installed at rope hitch in machineroom

3、 Illustration of the Appearance of Controller:

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]




Note: ①Hereinafter, Pj1.1 means the 1st place of Pj1 wiring port, successively analogizing. Its arrangement in the control is from left to right. ②The size of the whole set is shown in section 13, chapter 19 in detail.③Terminal wiring is described in Chapter 5.

4、 Illustration of the Appearance of Sensor and Install Method: (Take EWD-LG-SJ3 as an

example. And EWD-RLG-SJ3 sensor is installed in the same way)

A、 Standard “Disc” type Intelligent loading Sensor


①Installing and fitting scheme: See Fig.[3A]




Special Explanation on the customer-made rope shackle clamp: ①Based on the concrete condition; ②The distance between Line "A" and "B" in the above figure should be divided equally referring to the center of the traction force; ③Assure to fix the sensor and its auxiliary support well with the screw sets along with the system; ④The pull rod through hole should be larger 3~5mm than the original hole for the convenience of the movement of the pull rod. ⑤The clamp thickness should not be less than 15mm.

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

② **Appearance and Structure of Sensor:** [EWD-GA sensor] See Fig[3A]




B、Standard Character “E” Type Intelligent Tension Sensor (Sensor of EWD-GB) See Fig【3B】



C、Standard Convex Type Intelligent Stress Sensor (Sensor of EWD-GC) Just for EWD-LG-SJ3


Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

See Fig [3C]



D、Standard Character “—” Type Intelligent Load Sensor (Sensor of EWD-GD) Just for

EWD-RLG-SJ3 See Fig **[3D]**




5、 Description of the System Controller Terminals:

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Being effective when selecting floor-by floor compensation methods:

1. If floor-by-floor compensation is unnecessary, this port is unwired; ;
2. Adopting fuzzy compensation, this port is unwired, refer to attached Figure [1];
3. Adopting “up and down leveling” compensation method, refer to attached Figure [2];
4. Adopting “door zone + traveling direction” compensation method, refer to attached Figure [3];
4. Triggering Voltage of PX.1~2、PX.3~4 is DC12~32V, the way of triggering method is decided by the manual setting of “PH”
6. The compensation method is differentiated by the system automatically after the wiring of PC ports is completed, and the results will be stored in parameter “P5”;
7. PX.5~6 is the control signal for output locking to be connected to door interlocking circuit. Note: With the adoption of landing compensation, be sure to power on the circuit.



Detailed Explanation of the Controller Terminals:

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

		Function	Explanation		
PJ	Switching	.1	COM of J1~2 Relay	In coordination with Pj.2~4 to produce effective logic	1. Effect : Be programmed as“no load~overload”output signals to participate in elevator logic control 2. Max loading Capacity: DC/AC 48V/500mA
		.2	J1 Relay Output Terminal	System Default“J1”: No load Output ;	
		.3	J2 Relay Output Terminal	System Default “J2”: Rated load Output ;	
		.4	COM of J3 Relay	In coordination with Pj.5~6 to produce effective logic	
		.5	J3 Relay Output Terminal	System Default “J3” : Overload Dyn Close Output ;	
		.6	J3 Relay Output Terminal	System Default “J3” : Overload Dyn Open Output ;	
	Analog	.7	Analog Voltage Output: 0~10V; -10~+10V; 0~+5V	Being used for pre-torque compensation for driving system	
		.8	COM connected to analog common terminal of speed regulator		
PX	5 _[+] ~6 _[+]	Lock output signal control terminal. Be connected in system door lock signal circuit, pay attention to connecting polarity.			
PS/PG		For EWD-LG-SJ3: To Connect PS to the communication terminal of GW1 transducer For EWD-RLG-SJ3: To Connect PG to the sensor along with signal cable			
PV		System Power Supplying Terminal: AC/DC24V / 200mA			
PX		Parameter P5=2	Parameter P5=3	Parameter P5=4	1. No wiring: system unnecessary of landing compensation; 2. System may accurately control elevator floor-by-floor compensation to interpolate the dead weight floor error caused by cable, rope and
	1 _[+] ~2 _[-]	Down leveling signal (Up leveling Sensor)	Signal of Elevator entering leveling zone or door zone	/	
	3 _[+] ~4 _[-]	Up leveling signal (Down leveling Sensor)	Elevator Up traveling Signal	Main floor signal	

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	compensation cable; 3.This terminal defaults positive skip of input signal being effective and the enabling method of PX3.1~2、PX3.3~4 depends on parameter "PD". 4.See attached figure for wiring.
--	--

① Absolutely don't connect the output terminals (except "PV") of this device to the external power source directly and the resulted permanent damage to the device is beyond our responsibility.

② Attention: As for the input signal of "PX" terminal, a requirement of polarity is needed, PX.1、3 and PM.1 are "+", and the corresponding circuit voltage should be "DC 12~32V".

Installation and Adjustment

6、 Schematic Diagram for System Construction and Installing Method:

- ① Schematic Diagram of the appearance of the whole set: Controller Section See Fig. [2]
 - ② Sensor Section: "Disc" type See Fig. [3A]; Fig. [3B] for Character "王" type, Fig. [3C] for Convex type, Fig. [3D] for Character "一" type.
 - ③ Schematic Diagram for "Disc" type load sensor installing method See Fig. [3A.1];
 - ④ Schematic Diagram for Character "王" type tension sensor installing method See Fig. [3B];
- 1) Option of **EWD-LG-SJ3**: EWD-GB intelligent sensor and EWD-GW1 remote transducer;

2) Option of **EWD-RLG-SJ3**: EWD-GB sensor

⑤ Schematic Diagram for Convex type tension sensor installing method See Fig. [3C];

1) Option of **EWD-LG-SJ3**: EWD-GC intelligent sensor and EWD-GW1 remote transducer;

2) Option of **EWD-RLG-SJ3**: Currently, no option.

⑥ Schematic Diagram for Character “—” type load sensor installing method See Fig. [3D];

1) Option of **EWD-LG-SJ3**: EWD-GD intelligent sensor and EWD-GW1 remote transducer;

2) Option of **EWD-RLG-SJ3**: EWD-GD sensor

7、 Install Method of Sensor and Controller:

① Adjust traction ropes so that the pull of each rope keeps coincident.

② A: “Disc” type sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3A.1] and Fig. [3A.2] with customer-made shackle clamp plate.

B: Character “王” type tension sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3B] and refer to it for more details.

C: Convex type tension sensor is installed in the middle of the car-top bearing beam according to Fig. [3C] and refer to it for more details.

D: Character “—” type load sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3D] with customer-made shackle clamp plate.

③ Control Section should be installed in the control cabinet placed in machineroom, being away from equipments such as the transformer, speed regulator of elevator electric control system. Under any


Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

condition, sensor and controller should be far away from heat source.

- ④ It would be better not to put the connecting cable between sensor and controller in the same wire duct with dynamic power of 110V or 220V.
- ⑤ Connect the sensor wiring terminal to PS terminal of the control, simultaneously, connect power line to PV according to system requirement. Pay attention to the voltage level.
- ⑥ When no error is inspected, power on the system and the corresponding operation patterns will be displayed on the control.

8、 Adjustment Method and Description of the System (Autotune Operation)


① Initialization: Selection of Compensation Method




Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

② Lock the dead weight of elevator car:


Let personnel leave car and car top and stop elevator at the bottom floor leveling position. Then adjusting personnel enters machineroom. When [Lo] is displayed on the control, press key [π] and [θ] simultaneously. When system displays "Pn", test and inspection is completed, and [PL] and [01] will be displayed alternatively



③. No load Autotuning Operation Mode:



④ Rated Load Autotuning Operation Mode:



⑥ System adjustment under other conditions:

For following reasons, the parameters of this system need re-modifying in the way described above.

- 1) Elevator car decoration changing causes its dead weight change.
- 2) Larger unbalance appears among traction ropes.
- 3) Sensor of weighing device becomes flexible.
- 4) Overrunning at the top or at the bottom occurs.

Operation Parameters Adjustment and the Implication

9、 System Operation Parameters Adjustment (Annotation: * represents for a

hexadecimal value of “0~9,A~F”.)

- ① Simultaneously press **【π】** and **【θ】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering operation parameters modifying status.
- ② Release **【π】** and **【θ】** buttons, system will display **【P*】** and **【**】** alternately. **【P*】** is an indication of system operation parameters; **【**】** is the interior data value of **【P*】** .
- ③ When displaying **【P*】** , press **【θ】** , indication of system operation increases; press **【π】** , indication decreases.
- ④ When displaying **【**】** , press **【θ】** , data value increases; press **【π】** , data value decreases.
- ⑤ Release buttons, system displays operation indication and configuring data alternately.
- ⑥ To modify other configuring datum, repeat the operation in item 3, item 4, and item 5.
- ⑦ At the moment when system displays **【P*】** , Simultaneously press **【π】** and **【θ】** , system will save modified datum for future use. This moment, system displays **【Pn】** for 1 second. System operation parameters modification of this time is completed.

Example: Modify parameter PD to 03; (PX.1~2、PX.3~4 enabling for low voltage level compensation signal)

- ① Simultaneously press **【π】** and **【θ】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering modifying status.
- ② Release **【π】** and **【θ】** buttons, system will display **【P0】** and **【**】** aglimer
- ③ When displaying **【P0】** , press **【θ】** to increasing it to **【PD】** ;
- ④ Release button **【θ】** , system alternately displays **【PD】** and **【**】** .
- ⑤ When displaying **【**】** , press **【π】** or **【θ】** to regulate its value as **【03】** .

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

⑥Release button, system alternately displays [PD] and [03] .

⑦At the moment when system displays [PH] , Simultaneously press 【π】 and 【θ】 , system will save modified datum for future use. This moment, system displays [Pn] for 1 second. System operation parameters modification is completed.

10、 Implication of parameter P: Normally, it is unnecessary to modify parameter after “P0”. System may automatically modify them in the course of Autotuning.

① Directions of Parameter **P0** [System Operation Mode]:

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation (Automatically modify by system after autotune.)	01 (Sensor Positioning)	00 System Auto Modifying
01	Sensor positioning, system autotuning		
09	Options for dealing with abnormality when Selecting“王”type intelligent sensor.		
0A	Forcibly set system settings as default values		

② Directions of Parameter **P1** [System Rated Load Setting Mode]:

Setting	Explanation	Default Setting	Normal Value
01/02或 05~55 ×100Kg	01— Select“100% Rated load, floor by floor” Autotune 02— Select“20% Rated load, floor by floor” Autotune; **—Select rated load setting mode(Not Recommended)Example: “10”means rated load of 1000Kg. There is a certain error in this method. <i>Note: This mode is just for type “D” sensor.</i>	01 (Rated load Autotuning)	

③ Directions of Parameter **P2** [The Highest Elevator Landing Setting Mode](Automatically modify them in the course of Autotuning by system):

Setting	Explanation	Default Setting	Normal Value
01~32	Setting elevator landings: Selection of 01 means ceasing floor compensation function.	99 (landings)	System automatically modifies them in the course of Autotuning.

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	Input signal of PX is ineffective this time.		
--	--	--	--

④ Directions of Parameter **P3** [Setting Elevator Shutdown at Main Floor]:

Setting	Explanation		Default Setting	Normal Value
01~19	Higher Bits	Lower Bits	01(landing) Effective when switched on, and with the basement floor is main floor.	System auto modification in fuzzy compensation autotuning
	0—"PX.5~6" effective for Low Voltage Level; 1—"PX.5~6" effective for High Voltage Level;	Setting elevator main floor. Example: Selecting 2 means there is a basement floor for this elevator.		
	Example: Selecting 12 means "PX5~6" effective for Low Voltage Level and there is a basement floor for this elevator.			

⑤ Directions of Parameter **P4** [Time Parameter for Floor-by-floor Compensation]:

Setting	Explanation		Default Setting	Normal Value
00~99	Higher Bits	Lower Bits	42 Anti-interference protection time of each floor is 2.0 seconds; Control Factor of fuzzy compensation is 2.	
	Anti-interference protection time of each floor : 0~9×0.5 Second;	Control Factor of fuzzy compensation: 0~3		
	0-Not Enabling protection time			

⑥ Directions of Parameter **P5** [Selection of Floor compensation input signal function] (Automatically modify in the period of Autotuning by system):

Setting	Explanation					Default Setting	Normal Value
	00	01	02	03	04	00 (Auto Measuring)	Auto modified by system in the period
	Allow auto deciding compensation method	Disable	up/down leveling step counting control	Door zone + running direction Control	Fuzzy compensation		

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

00~03	Notes: 1. See Section 1, Chapter 8 and attached drawings for more details; 2. Elevator of serial communication control may use "03" or "04" operation method. Running direction Signal may be parallel connected to the forward rotation command signal of the SPECIFIED inverter.		of [Lo]displaying.
-------	---	--	--------------------

⑦ Directions of Parameter **P6** [Logic condition Setting Relay“J1”, “J2”, “J3”]:

Setting	Explanation				Default Setting	Normal Value
	Higher Bits	Lower Bits				
00~17	0---	Contact Status	J3	J2	J1	20 (Relay Dynamic Close output, analog output of 0~10V is effective)
	Selecting 0~10V					
	1---	0	Dynamic Close	Dynamic Close	Dynamic Close	
	Selecting 10~0V	1	Dynamic Close	Dynamic Close	Dynamic Open	
	2---	2	Dynamic Close	Dynamic Open	Dynamic Close	
	Selecting -10~10V	3	Dynamic Close	Dynamic Open	Dynamic Open	
	3---	4	Dynamic Open	Dynamic Close	Dynamic Close	
	Selecting +10~-10V	5	Dynamic Open	Dynamic Close	Dynamic Open	
4---	6	Dynamic Open	Dynamic Open	Dynamic Close		
Selecting 0~-+5V	7	Dynamic Open	Dynamic Open	Dynamic Open		

⑧ Directions of Parameter **P7** [Setting Relay“J1”Operation Range]:

Setting	Explanation	Default Setting	Normal Value
00~99 A0~A9 b0~b9	When Load \geq Rated load \times P7%, “J1”signal is output.	05 Setting J1: actuating for 05% Rated Load	
	00~99: Actuating for 0~99% rated load		
	A0~A9: Actuating for 100~109% rated load		
	b0~b9: Actuating for 110~119% rated load		
	C0~C9: Actuating for 120~129% rated load		

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

C0~C9 d0~d9 E0~E9 F0~F9	d0~d9: Actuating for 130~139% rated load			
	E0~E9: Actuating for 140~149% rated load			
	F0~F9: Actuating for 150~159% rated load			
	Example	P7=80: For effective load of 1T, system actuates at 800Kg.		
P7=A5: For effective load of 1T, system actuates at 1050Kg.				
P7=C5: For effective load of 1T, system actuates at 1250Kg.				

⑨ Directions of Parameter P8 [Setting Relay“J2”Operation Range]:

Setting	Explanation	Default Setting	Normal Value
The same as P7	The same as P7: When load \geq Rated Load \times P8%, output “J2”signal	A0 Setting“J2”, system actuates at 100% rated load	

⑩ Directions of Parameter P9 [Setting Relay“J3”Operation Range]:

Setting	Explanation	Default Setting	Normal Value
The same as P7	The same as P7: When load \geq Rated Load \times P9%, output “J3”signal	A5 Setting“J3”, system actuates at 105% rated load	

Ⓜ Directions of Parameter PA [No-Load Auto Zeroing Time Interval]:

Setting	Explanation	Default Setting	Normal Value
00~96 (Hours)	When it reaches the set time, system will begin the operation of no load zeroing automatically. 01—— System disables the function of no load auto zeroing. 12~96—After system powered on (for 12~96 hours), it begins the operation of inspecting load detaining time, a part of no load zeroing operation.	00(Disable)	

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

12 Directions of Parameter **PB** [Detaining Time of No-Load Auto Zeroing]:

Setting	Explanation	Default Setting	Normal Value
10~90 (Minutes)	After auto zeroing time is reached, system load doesn't change in this period and system will allow the beginning of No-Load Auto Zeroing operation.	30(Minutes)	

13 Directions of Parameter **PC** [No load Auto Zeroing Error Range]:

Setting	Explanation	Default Setting	Normal Value
03~20 (%)	When conditions of both (7) and (8) being satisfied and the ratio of present load to the absolute value of original no load is larger than this setting, system begins No load Auto Zeroing operation immediately.	05% (No load Error larger than 5%, System)	

14 Directions of Parameter **PD** [Characteristics of Compensation Terminals]:

Setting	Explanation			Default Setting	Normal Value
00~03		PX.1~2	PX.3~4	00 PX.1~2、PX.3~4 Effective for High Voltage Level	
	00	Effective for High Voltage Level	Effective for High Voltage Level		
	01	Effective for Low Voltage Level	Effective for High Voltage Level		
	02	Effective for High Voltage Level	Effective for Low Voltage Level		
	03	Effective for Low Voltage Level	Effective for Low Voltage Level		

15 Directions of Parameter **PE** [Selection of Sensor Parameters]:

Setting	Explanation					Default Setting	Normal Value
80~90	D7~D4	D3	D2	D1	D0	84 Standard Sensor , 2 gain-Levels for selection	
		Sensor Gain Adjustment 0 ~ 3 gain-Levels for selection			0-Standard Sensor 1-Modification of "Convex" type stress sensor picking-up abnormality.		
	Recommendation: Normally, users don't need to adjust this parameter. Any dissidence, contact with						

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

the manufacturer directly.

- Attentions:
- ① When selecting not indicated settings, system will not normally operate.
 - ② No load auto zeroing parameters PA, PB and PC should be used cautiously because of the cause variety of elevator no load point drifting. It is recommended for the user to allow or forbid this function according the concrete conditions.
 - ③ Even if No load auto zeroing operation enabled, in the course of elevator periodical maintenance, autotuning operation of this system should be redone without exception.

Explanation of Displaying Code:

11、 System Normal Operation Code:

【J0】	【J1】	【J2】	【J3】
No Relay Output	RelayJ1 Output	RelayJ2 Output	RelayJ2 Output
	Default 5% of Rated Load	Default 90% of Rated Load	Default 105% of Rated Load
<p>1. Displaying “HJ※※※※”when pressing【π】button indicates present car effective load. For instance, displaying“HJ0520 ”indicates the load of 0520kg.</p> <p>2. Displaying “.※. ※.” when pressing 【θ】 button or in the course of landing changing indicates present system compensating landing. Adjusting Personnel may judge whether system compensating landing tracing is right or not by its numerical value. Note: This option is just for floor-by floor compensation method.</p> <p>3. Displaying “0.0.”in fuzzy compensation indicates compensation is effective. Displaying “0.1.”indicates elevator entering modifying zone.</p>			

12、 Code for Other Operation and Failures

	Display Code	Indication	Solution
1	FY	System Startup	

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	Display Code	Indication		Solution
2	PC	Sensor Resetting		
3	PP	Get into the status of operation parameters modification		
4	PL	Autotuning No load parameters		(Still Displaying indicates preparation status, aglimmer displaying indicates the end of inspection)
5	PH	Autotuning Rated load parameters		
6	LL	Installation and positioning	Too big Positioning	Sensor having no load
7	LH		Too small Positioning	Sensor overload
8	Lo		Accurately Position	
9	LP		Interior Auto Correction	
10	LY		Forcibly skip sensor interior auto correction	
11	P*		System Configuration Indication	
12	Pn	Saved		
13	EA	Saving Failure		Modifying operation parameters again
14	EJ	Without this system setting		Check system settings
15	EH	Applied Overflowing Pressure		Sensor pressure may beyond its withstanding range
16	EL	Applied Insufficient Pressure		Sensor being not pressed
17	EE	No landing of this code		Make certain PC signals abnormality or no load autotuning normal or not
18	EF	Memorizing abnormally		Repeat this operation.
19	ES	Communication Failure		Carefully check wiring between sensor and control.

How to do?

13、Brief Analysis of Other Conditions:

(1)Bad system Operation Stability with the main indication of large output fluctuation in the condition of fixed load

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

and elevator motionless?

Check if PV power supply source fulfils system requirements?

(2) After long-term of operation, system no load zeroing point appears larger deviation?

May be caused by the reason described in section 8, chapter 8. Set system Autotuning mode to calibrate again, or startup parameter "PA≠0" to realize the function of system no load auto zeroing.

(3) System displaying failure code $[[EE]]$?

Incorrect Input signal of terminal PX on the control or unreasonably setting.

(4) When selecting floor indication step counting control method, floor-by-floor compensation consistency is bad?

Whether up or down landing signals or leveling signal is normally wiring, Setting of parameter P5 is reasonable?

(5) Traveling Up and down with the same load and stopping at the same floor, but the weighing result is different?

① *Lift rope pull is not symmetrical, adjust please.*

② *Elevator guide shoes are too tightened, running friction is large. It is recommended to adjust or modify relevant mechanical part to make it move flexible, then operate the system to autotune again.*

(6) System output signal doesn't change linearly along with load?

Maybe system sensor is damaged.

(7) How to descry present effective load of elevator car?

① *In the period of system normal operation, press button $[\pi]$. This moment, system displays $[[HJ]] \rightarrow [**] \rightarrow [**]$. For example : displaying $[[HJ]] \rightarrow [09] \rightarrow [50]$ indicates a car with rated load of 1000 Kg presently bearing an effective load of 950Kg.*

② *If elevator effective load is not 1000 Kg, it may be decided after system autotuning operation is finished by modifying parameter "P1".*

③ *Because of various impacts from outer environment, displayed data may fluctuate in a small scope.*

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

(8)When elevator is motionless, weighing signal is normal. But in the course of door opening, it is abnormal?

Elevator door operation system causes relative car weight offset. It may be controlled by adopting door opening/closing relay output signals+ door lock signal jointly participating system Pj4 locking.

(9)How to determine car dead weight(This operation is effective for type A and D sensor and “EWD-LG-SJ3#”type)?

- a. *After modified parameter “P0=11” is saved, this moment, system displays $[\text{HP}] \rightarrow [**] \rightarrow [**]$; For example: displaying $[\text{HP}] \rightarrow [15] \rightarrow [10]$ means car dead weight of 1510Kg.*
- b. *Because of various impacts from outer environment, displayed data may fluctuate in a small scope. Users may adopt algorithm of average value of several times to deal with inspection results. Meanwhile, inspection accuracy may be influenced by self-made traction rope clamp and traction ropes tension equality.*
- c. *Press $[\pi]$ or $[\theta]$ ad arbitrium, system may reset to original setting.*

(10)During system operation, analog output is abnormal, repeatedly resetting or abnormal coordination with speed regulator?

May be caused by crossing and interfering system power source. Select another set of power source to supply power to system, or equip AC/DC 24V/300mA exterior power source to supply power.

14、 How to Repeat doing Autotune operation for system?

Method 1: Simultaneously press $[\pi]$ and $[\theta]$ on system control panel to power on. This moment, system aglimmer displays $[\text{PP}]$ and $[\text{P-}]$. Keep 10 seconds, system will display $[\text{Pn}]$. On that occasion, all operation parameters reset to default settings.

Method 2: Modifying parameter P0=0A will reset system immediately to default status. But for users with specified code, it is necessary to modify parameter P0 as appointed code. Detailed operation is described in chapter 9.

15、 How to adopt 20% rated load for rated load autotune?

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

After system displaying [Lo], modify parameter“P1=02”.Do no load autotuning operation as described in chapter 6. In the period of displaying [PH], load elevator car with a weight equal to 20% of rated load to do rated load autotuning operation. When operation is finished, [L1] is displayed.

16、 How to do “Weight Setting” autotune for EWD-GA type sensor? (Just limited to

EWD-GD. Affected by mechanical system, having certain error)

After system displaying [Lo], modify parameter“P1=elevator effective load”(For 1ton, input10; 3 tons, input 30). Do no load autotuning operation as described in chapter 5. When operation is finished, [J0] is displayed.

17、 How to get the version code of the product?

After power off, press 【0】 to supply power. System displays [1.0] indicating the corresponding User's Guide of this product being Version“V1.0”.

System Features

18、 Main Characteristic:

- (1) Selecting super thin “Disc” type intelligent load sensor, it is capable of directly inspecting elevator car load change unnecessary to change the pull rod of traction rope shackle;
- (2) Weighing range is wide (effective load of 500Kg~5500 Kg), high-accuracy position, intelligent temperature compensation.
- (3) Electric property complies with the requirements of “International Electro-technical Commission (IEC) ”Standard.

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

- (4) Inner core consists of highly accurate load sensor and high performance single-chip micro-computer. All operation parameters can be set on field.
- (5) Auto on-site measuring of various compensation methods, boosting requirement of high accuracy weighing signal of elevator system.
- (6) System may do scientific calculation according to mathematical equations with the function of no-load auto zeroing, automatically modifying measuring error.
- (7) Directly displaying present effective load. Some types may directly measure dead weight of elevator car for the benefit of users.
- (8) Field adjustment may select 20% or 100% rate load autotuning method or load setting method, being easily adjusted and operated.
- (9) Independent development of the method of **Programmable Output Signal Control** is suitable for all the requirement of traction elevators with various kinds of fixed car platform.
- (10) Having the function of operation parameters auto modification, auto accommodation to multi methods of intelligent floor compensation function, being applicable to traction elevators of less than 30 landings.
- (11) Distinctive design structure of sensor+ controller, only 2 connecting wires between sensor and controller making wiring simply.
- (12) The whole shoot starts from users' point of view, easy installation and adjustment, decreasing users' additional cost in use, high ratio of performance to price.

19、 Technical Specifications:

1. Application	Being applicable to all traction elevators fixed car platform (less than 60 landings) with the load of 500 kg ~ 5000 kg .
2. Floor	Auto accommodating to the following compensation methods: ①Up and Down leveling; ②Up

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	Compensation:	command + door zone; ③Fuzzy and intelligent.		
3.	Sensitivity	Elevator Rated Capacity/200 (Example: The rated capacity is 1000 kg, and the sensitivity is 5 kg) [This data may be affected by elevator mechanical performance.]		
4.	System Error	$\leq 0.5\%$ (5~40°C)		
5.	Non-Linearity	$\leq 0.5\%$		
6.	Compensation	The method of circuit parallel connection is applicable to the signal source system of DC12~32V. Also, the interior fault of this system doesn't affect the original operation mode of elevator.		
7.	Output Mode	Relay	Programmable universal signal	①3-channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, and overload (customer may set the changing range freely). ②Each channel can be programmed as dynamic Close or Open contact. ③Contact Capacity: DC/AC 48V/100mA
			Analogue quantity	Overall Compensation Range 0 ~ 10V, -10V ~ +10V, 0V ~ +5V
8.	Ambient Temperature	Temperature: -20~55°C		
9.	Relative Humidity	20%~90%RH		
10.	Reaction Time	≤ 0.5 Second, The communication distance between the intelligent and the control is 0~400m.		
11.	Power Supply:	AC/DC24($\pm 10\%$)V / 200mA		
12.	Installation Place	Sensor Section: At the place of traction rope shackle Controller Section: Control Cabinet in machineroom. See the figure 3 for installing dimension.		
13.	Overall Size:	Sensor Section: See the figure [3]; Controller Section: 115×90×40 mm ³		

: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.


Promise


- (1) If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with)。
- (2) For any requirement of special functions, make it out by mail.
- (3) Any system abnormality in adjustment or operation, please contact our company directly.


Others:


<p>1.Packing List:</p>	<p>Type A: Intelligent “Disc” type load sensor</p> <p>Sensor Auxiliary Support <i>M10×35mm</i> Fastening Screw sets 1</p>	<p>1Set</p> <p>1</p> <p>6 sets</p>	<p>Type B: Intelligent Character “王” tension sensor</p> <p>Type C: Intelligent stress sensor</p>	<p>1set</p> <p>1set</p>
<p>2.Address book:</p>	<p>Type D : Intelligent Character “—”load sensor</p> <p><i>M10×35mm</i> Fastening Screw sets 2 sets</p> <p>EWD-GW1:Remote transducer (Just for EWD-LG-SJ3) <i>M4×20mm</i> Fastening Screw User’s Guide</p>	<p>1 set</p> <p>2 sets</p> <p>1 copy</p>	<p>EWD-LG-SJ3/EWD-RLG-SJ3 controller</p> <p>$\Phi 4 \times 40 \text{mm}$ Fastening Screw sets</p>	<p>1</p> <p>4set s</p> <p>1set 2 sets</p>

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

 : (029)88416613, 18092639750


 : 7D, Block A, Olympic Building,
14th Chang An North Road,
Xi'an, Shaanxi,China

 : (029)86698830

 : 710068

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]


Att. Fig [1]: Wiring Method of Terminal PX in the mode of parameter “P5=4” (Auto accommodating fuzzy floor compensation)



Recommended Application Range of this mode: All elevators with better mechanical installation characteristic.

- Notes:**
1. Directly parallel connect PX.3~4 and PX.5~6 to corresponding electric circuit. If user selects “mid landing” position signal, more accurate compensation effect may be received.
 2. PX.3~4 must be connected to corresponding signal circuit. In fuzzy compensation autotuning, system auto modifies higher bits setting of parameter P3 to determine the enabling method of this signal(System default is that in the period elevator stops at main floor, “main floor position signal switch” is in closed condition.).
 3. Voltage of terminal COM should be in the range of “DC12~32V” .

Att. Fig [2]: Wiring Method of Terminal PX in the mode of parameter “P5=2” (Leveling Signal Control)




Recommended Application Range of this mode: Elevator having “up leveling” and “down leveling” input signals or allowing to add leveling device in hoistway;

- Notes:**
1. Directly parallel connect PX.1~2, PX.3~4 and PX.5~6 to corresponding electric circuit;
 2. PX.1~2 and PX.3~4 must be connected to corresponding leveling signal circuit. User may select Close Enabling or Open Enabling according to concrete conditions. Please notice manual setting parameter PJ (system default is that in the period elevator leveling, “leveling signal switch” is in Closed condition.).
 3. Voltage of terminal COM should be in the range of “DC12~32V” .

Technical File of EWD-LG-SJ3/RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Att. Fig [3]: Wiring Method of Terminal PX in the mode of parameter “P5=3” (Door Zone+ Running Direction Control)



Recommended Application Range of this mode: Elevator having “Door zone sensor” and “Upward running command” signals.

- Notes:**
1. Directly parallel connect PX.1~2, PX.3~4 and PX.5~6 to corresponding electric circuit. Meanwhile, pay attention to the “upward running” signal picking-up points “A” and “B”.
 2. PX.1~2 must be connected to door zone signal circuit. (system default is that in the period elevator leveling, “door zone signal switch” is in Closed condition.), PX.3~4 must be connected to upward traveling command signal circuit. (system default is that in the period of upward traveling, circuit “PX.3~4” exists an operation voltage of “DC12~32V”). User may select Close enabling or Open enabling according to concrete condition. Pay attention to manual setting of parameter PJ.
 3. Voltage of terminal COM should be in the range of “DC12~32V”