

EWD-H-XJ3

USER' S GUIDE

(V1.5)

Xi'an Excellent Electromechanical Co., Ltd.

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

Table of Contents

Product Overview	1、Product Appearance, inner structure and interface directions	Page 2
	2、Exterior dimensions and installing diagram	Page 5
Installation & Adjustment	3、System Adjustment and directions	Page 6
Implication and Adjustment Method of the Operation Parameters	4、System Parameters Adjustment	Page 9
	5、Explanation of the Meaning of Parameter P	Page 10
Indicating Code Explanation	6、Explanation of System Normal Operation Code	Page 15
	7、Explanation of other displaying	Page 16
How To Do?	8、Brief introductions of conditions	Page 17
	9、How to do setting adjustment of an elevator with the known “no load→rated load” compressing deformation?	Page 17
	10、How to repeat the Autotune operation for the system?	Page 18
	11、How to modify the system output conditions after Autotune ?	Page 18
	12、How to Obtain the Product Version Code?	Page 18
	13、Further Explanation of EWD-H-SJ3 multi-function terminals “P5、P6”	Page 18
	14、How to do Rated Load Autotune by adopting 20% rated load?	Page 19
	15、Compression of car damping rubber exceeds sensor detecting range	Page 19
	16、On the adoption of the method “load increasing, displacement aloof ”	Page 19
	17、Working principle of “EWD-H-J3/J5/SJ3” elevator weighing device	Page 19
System Characteristics	18、Main Properties	Page 19
	19、Technical Items	Page 20
Promise		Page 21
Others		Page 21

Caution: This system is applicable an elevator with [moveable car platform] . Before use, please read the following content

Technical File of the EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

carefully.

The Inductive magnet is specially-made rare-earth magnet for this product with strong magnetic force. Special care should be taken during installation. Under no condition should it be away from the high temperature above 100°C to avoid demagnetizing and the equipment damage and personal hurt from this is beyond our responsibility.



Notice: Our part is just responsible for the products quality in the guarantee period under any condition.

Declaration: Our company reserves the right of changing products for technical improvement and the related technical parameters should be referred to the USER' S GUIDE along with the products.

Product Overview


1、 Product Appearance, Interior Structure and Interface Directions:

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

		<i>EWD-H-XJ3</i>	
Appearance			Interior Structure
			
<i>P1</i>	Com	Common terminal "Com" : 2-channel solid-state relay output	
<i>P2</i>	J1		
<i>P3</i>	J2		
<i>P4</i>	J3		
<i>P5</i>	<i>System Power Source:</i> DC/AC24V ($\pm 10\%$) / 150mA		
<i>P6</i>	Absolutely not to connect the output terminals of this device except " P7 、 P8 " to exterior power source directly, and the permanent damage from this is beyond our responsibility.		
<ol style="list-style-type: none"> 1. <i>J1~J4</i> are interior solid state relays with Max. loading capacity of DC/AC 32V/50mA. 2. To be programmed as "no load~over load" output signal to participate in elevator logic control. 			


2、Exterior Dimensions & Installing Scheme

Exterior Dimension




Notice on Installation

1. Install this device as near as possible to the center of elevator car platform or the original place of elevator overload switch. The system should be installed on the bottom bearing beam of elevator car platform with the inductive magnet adhering to the moveable car platform and the marking surface facing to the inductive point of the weighing device.
2. The system supporting frame should be made according to elevator concrete situation with the uneasily deforming material of thickness more than 4mm or with enforcing plate to avoid swaying.
3. Adjust this device so that the car platform magnet aiming to the center point of its upper section. Meanwhile, assure that the section of this device parallel to that of the magnet.



3、 System Adjustment and Directions

① System Positioning Operation:



② No load and Rated Load Operation Parameters for Autotuning:

When displaying [Lo], press【 】and【 】simultaneously, the system will start no-load operating parameters autotuning. When [PL] is displayed aglimer for 5s, it is the end of no-load autotuning.

yes

System will automatically enter the condition of rated-load autotuning. Displaying[PH]means the ready condition of rated-load autotuning.

yes

1. Displaying [PH] means put elevator in the condition of rated-load. (eg: for elevator with RL=1000Kg, load 1000Kg);
2. Press 【 】 system will begin RL parameters autotuning
Displaying [PH] aglimer for 4s, system will reset automatically.

yes

Displaying [L4] means the end of RL operating parameters

yes

By now, system RL autotuning is finished. System will enter normal operation condition. For the meaning of displaying code, please refer to **Chanter 7**.

By the way of setting

Displaying [L0] means the end of RL operating

yes

③ System Adjustment under other conditions:

For the following reason, it is necessary to modify the operating parameters of this device.

- ①For elevator car decoration change, the dead weight of the moveable car platform changes;
- ②The car platform appears mechanical deformation;
- ③The temperature difference between winter and summer has an unneglecting effect on the elastic coefficient of car platform damping rubber;
- ④The car platform appears damping rubber appears aging or deforming;
- ⑤The elevator overruns at the top or at the bottom;
- ⑥The weighing device becomes slack at the fixing end.

Operation Parameters Adjustment and the Implication

4、System Operation Parameters Adjustment (Annotation: * represents for a hexadecimal value of “0~9,A~F”.)

- ①Simultaneously press **【π】** and **【θ】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering operation parameters modifying status.
- ②Release **【π】** and **【θ】** buttons, system will display **【P*】** and **【**】** alternately. **【P*】** is an indication of system operation parameters; **【**】** is the interior data value of **【P*】** .
- ③When displaying **【P*】** , press **【θ】** , indication of system operation increases; press **【π】** , indication decreases.
- ④When displaying **【**】** , press **【θ】** , data value increases; press **【π】** , data value decreases.
- ⑤Release buttons, system displays operation indication and configuring data alternately.
- ⑥To modify other configuring datum, repeat the operation in item 3, item 4, item 5.
- ⑦At the moment when system displays **【P*】** , Simultaneously press **【π】** and **【θ】** , system will save modified datum for future use. This moment, system displays **【Pn】** for 1 second. System operation parameters modification of this time is completed.

Example: Modify parameter P2 to 16;

- ①Simultaneously press **【π】** and **【θ】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering modifying status.
- ②Release **【π】** and **【θ】** buttons, system will display **【P0】** and **【**】** aglimer
- ③When displaying **【P0】** , press **【θ】** to increasing it to **【P2】** ;

EWD-H-XJ3Intelligent Elevator Load Weighing Device [User's Guide]

- ④Release button **【0】** , system alternately displays **[[P2]]** and **[[**]]** ;
- ⑤When displaying **[[**]]** , press **【π】** or **【0】** to regulate its value as **[[16]]** ;
- ⑥Release button, system alternately displays **[[P2]]** and **[[16]]** ;
- ⑦⑦At the moment when system displays **[[P2]]** , Simultaneously press **【π】** and **【0】** , system will save modified datum for future use. This moment, system displays **[[Pn]]** for 1 second. System operation parameters modification is completed.

5、Implication of parameter P:

1.Directions of Parameter P0 [System Operation Mode]: :

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation	01	00 This value will be modified in the course of autotuning.
01	Sensor installing positioning, system no-load and rated-load autotuning operation.		
02	Specifying system no-load autotuning operation.		
03	Specifying system Rated-load autotuning operation.		
04	Select “20% rated load” autotuning operation, being convenient for users special adjustment.		
25~99 ×0.1mm	For elevator with known “no-load→rated-load” compressing moveable car platform damping rubber pad, it may be set manually. The system may be put into use after system installation positioning. (This adjustment is very convenient for elevator manufacturers. For more detail, refer to Chapter 10.)		

2.Directions of Parameter P1

Setting	Explanation	Default Setting	User Setting
00、01 10、11	0-Stepped output 1-0dotted ourput	00 Stepped output, short circuit for holding	User do not modify

Technical File of the EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

3.Directions of Parameter P2 [No-load parameter setting]

Setting	Explanation	Default Setting	User Setting
00~30	When car load \leq rated-load \times P2%, output no-load signal.	05	

4.Directions of Parameter P3[light-load parameter setting]

Setting	Explanation	Default Setting	User Setting
P2+1~60	When car load \leq rated-load \times P3%, output light-load signal.	30	

5.Directions of Parameter P4 [light-load parameter setting]

Setting	Explanation	Default Setting	User Setting
P3+1~90	When car load \leq rated-load \times P4%, output semi-load signal.	70	

6.Directions of Parameter P5[Light-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P4+1~99	When car load \leq rated-load \times P5%, output heavy-load signal.	90	

7.Directions of Parameter P6[Semi-load parameter setting]:

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

Setting	Explanation	Default Setting	User Setting
00~20	Overload triggering value > rated-load + (rated-load × P6) %	05	

8. Directions of Parameter P7 [Operation Status setting of Solid state relay “J1”]:

Setting	Explanation		Default Setting	User Setting
00~1F	Higher Bit	Lower Bit	00 (No-load Dynamic Close)	
	When the status is active: 0—Contact Dyn Close 1—Contact Dyn Open	0- Select no-load operation 1- Select light-load operation 2- Select semi-load operation 3- Select heavy-load operation 4- Select rated-load operation F- Select over-load operation		

eg: “P7=02” represents J1 is the dynamic close output of semi-load signal

9. Directions of Parameter P8 [Operation Status setting of Solid state relay “J2”]:

Setting	Explanation	Default Setting	User Setting
00~1F	The same as the above	02 (semi-load dynamic close)	

10. Directions of Parameter P9 [Operation Status setting of Solid state relay “J3”]:

Setting	Explanation	Default Setting	User Setting
00~1F	The same as the above	04 (Over load dynamic close)	

11. Directions of Parameter D [[Displacement-expanding Setting]:

Setting	Explanation		Default Setting	User Setting
	Higher Bit	Lower Bit	01	

Technical File of the EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

01~03 11~13	0-load increasing, displacement closing. 1-load increasing, displacement apart.	1. Select sensor 0~9.9mm valid; 2. Select sensor 0~19.9mm valid; 3. Select sensor 0~29.9mm valid;	displacement closing , 10mm valid	
----------------	--	---	---	--

Notice: ①Select unindicated setting will lead to system abnormal operation.

②For the variety of the fleeting of elevator no-load point, special care should be taken in the use of PA, PB and PC for No-load auto-zeroing. It is suggested to forbid or to allow this function according to the user's concrete situation.

③Even if auto-zeroing function is in use, autotuning operation should be done again in the course of periodic maintenance.

Explanation of Displaying Code:

6、System Normal Operation Code: (“W” is the present effective load)

Display Code		Indication		
System displays [L*]	L0	No-load car	Output No-load signal	No-load: $00 \leq W \leq \text{Rated-load} \times P2\%$
	L1	Light-load car	Output Light-load signal	Light-load: $\text{No-load} < W \leq \text{Rated-load} \times P3\%$
	L2	Semi-load car	Output Semi-load signal	Semi-load: $\text{Light-load} < W \leq \text{Rated-load} \times P4\%$
	L3	Heavy-load car	Output Heavy-load signal	Heavy-load: $\text{Semi-load} < W \leq \text{Rated-load} \times P5\%$
	L4	Rated-load car	Output Rated-load signal	Rated-load: $\text{Heavy-load} < W \leq \text{Rated-load} + \text{Rated-load} \times P6\%$
	LF	Over-load car	Output Over-load signal	Over-load: $W > \text{Rated-load}$
[**] (only for EWD-H-SJ3)	0.0~9.9~10 displaying analog voltage %			
[U*] (only for EWD-H-SJ3)	8421 output		*-any value of 0~1F, $0 \leq * \leq \text{parameter} [P1]+1$ Displaying [Y*] means the tested value is larger than “0F”	

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

- ① Press **【π】**, system displaying **【4.7】** means the max compression “no load→rated load” of this moveable car platform is “4.7mm”. User may save this value for future use.
- ② Press **【θ】**, system will display the present moveable car platform load. Displaying **【1.2】** means the compression of “1.2mm” from no load condition.

For user to save: the code of this elevator Rated-load Compression: mm

7、Code for Other Operation and Failures

	Display Code	Indication	Solution
1	FY	System Startup	
2	Pc	System Resetting	
3	PP	Get into the status of operation parameters modification	
4	PL	Autotuning No load parameters (Static Displaying represents preparative status, twinkling displaying for the end of testing)	
5	PH	Autotuning Rated load parameters (Static Displaying represents preparative status, twinkling displaying for the end of testing)	
6	LL	Installation and positioning	Too big Positioning
7	LH		Move this device closing to the magnet
8	Lo		Too small Positioning
9	LP		Move this device away from the magnet
			Accurately Position
			Interior Auto Correction
10	P*	System Configuration Indication	
11	Pn	Saved	
12	EA	Saving Failure	Modify the operation parameters
13	EJ	Without this system setting	Check system setting value
14	ED	Car platform deformation deficient	Affirm elevator in the condition of rated load
15	EC	Car platform deformation overflowing	Damping rubber is too soft, adjust PD
16	EH	Incorrect installation place of the magnet	Check the magnet installation place
17	EL	Incorrect installation place of the magnet	Check the magnet installation place, pay

Display Code	Indication	Solution
		special attention to polarity and distance.

How to do?

8、Brief Analysis of Other Conditions:

- ①After installation of this weighing device, weighing signal changes in the course of operation?
The elevator load output value is not held after elevator starts, adjust the relative items of the inverter and controller.
- ②After long-term of operation, system no load zeroing point appears larger deviation?
May be caused by the reason described in section 3, Chapter 3. Set system Autotuning mode to calibrate again
- ③After the elevator weighing is changed from heavy load to light load, heavy load signal is still displayed?
The movement of the moveable car platform is blocked, it is not reset after pressing. Solute the relevant mechanic problems.
- ④System output signal doesn' t change linearly along with the change of load?
Check the structure of the moveable car platform, pay more attention that there should only be one pair of damping rubber or spring moving relatively to the moveable car platform.
- ⑤During the system operation, analog output is abnormal or system resetting or speed-regulator cooperation is abnormal?
It may be caused by system power source series interference. Select another group of power to supply the system, or to provide an exterior power of AC/DC 24V/300mA to supply.

9、How to set an elevator with known “no-load→rated load” compression deformation?

For example: The max “no-load→rated load” compression deformation of this elevator is 5.8mm.

- | | |
|-----------|---|
| Operation | <ol style="list-style-type: none"> 1.Modify “P0=58” and save it. Refer to chapter 5; 2.After system restarting, [LP] is displayed. Wait until [LL], [Lo] or [LH] is displayed; 3.When the car is empty, adjust system installation position to make it display [Lo], fasten it; 4.When [Lo] is displayed, press [π] and [θ] simultaneously, system begins to autotune no-load operation parameters; |
|-----------|---|

5. After [PL] is displayed for 5 seconds, the whole process of autotuning is finished.

10. How to do Re-Autotune operation for system?

Method 1: Simultaneously press **【π】** and **【0】** on system control panel to power on. This moment, system aglimer displays [PP] and [P-]. Keep 15 seconds, system will display [Pn]. On that occasion, all operation parameters reset to default settings.

Method 2: Modifying parameter P0=0A or user specified operation code will reset system immediately to default status. But for users with specified code. The method is mentioned in Chapter 5.

11. How to modify output status of a system after autotuning is finished?

Modify the corresponding controlling parameters of parameter P respectively. The method is mentioned in Section 6, Chapter 5.

12. How to get the version code of the product?

Press **【0】** to supply power. System displaying [L1] [20] [.] [1.2] means that this product is of V1.2 relatively to USER'S GUIDE.

13. More on “P5、P6” multi-function terminals of EWD-H-XJ3:

Lower bit setting of Parameter [P2]	Output status of terminal “P5~P6”		
	P5 --- “+” ; P6 --- “-”		
X 0	Analog	0~10V	For short distance connection, analog torque compensation speed regulation system is required.
X 1		10~0V	
X 2	Digital	0~10V	For user's selection of “ECW-AL1” remote transmitting system, analog of 0~1000 meters remote digitally transmitting
X 3		0~10V	

14、How to adopt 20% rated load for rated load autotune?

Modify P0=04. After [Lo] positioning and no-load [PL] autotuning, in the period of system displaying [PH], load 20% of the rated load, press [0], system displaying [L1] means the end of adjustment. This is an auxiliary method when 100% autotuning can be done.

15、The compression of car damping rubber exceeds the sensor inspection range?

Before autotuning, be assure to select “PD”=“02/03” and save it. Then, readjusting the installing position of the sensor is OK (See parameter PD for more details).

16、On adopting operation of “load increasing, displacement aloofing” method?

Before autotuning, be assure to select “PD” = “1*” and save it. Then, readjusting the installing position of the sensor is OK.

System Characteristics

17、Working principle of “EWD-H-XJ3” elevator weighing device

With the constantly development of elevator technology, the impact of elevator weighing device on elevator performance can not be neglected. The requirement of elevator for weighing devices with high accuracy, high reliability and multi-functions becomes extremely urgent. Presently, the progress of sensor technology and microcomputer is ceaseless. With the adoption of highly accurate Hall sensor, the change of displacement along with car platform load can be checked. Meanwhile, with the adoption of single chip microprocessor, scientific calculation can be done, making this device weigh the elevator car load effectively. With the cooperation of ECW-AL1 remote signal transferring device, analog or digital signal can be transferred far away, largely enlarging the user's application range and decreasing the additional cost in the course of use.

18、Main property

- (1) Working in a contactless and inductive way. No mechanical movement. Solid-state relay outputs. Being directly installed in the original place of overloading switch. No necessity of changing the mechanism of elevator car.
- (2) The whole system is designed in the waterproof structure with small overall size, easy installation and adjustment and simple structure.
- (3) Wide induction range, high accuracy positioning, intelligent temperature compensation making the range of

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

operating temperature wider.

(4) The inner core consists of Hall sensor of high accuracy and single-chip microprocessor of high efficiency. All parameters may be set on the field.

(5) Having the controllable function of “automatically return-to-zero at no load”

(6) Having the analog voltage output ports, greatly improving elevator performance in coordination with elevator speed regulator.

(7) Having the function of remote digital communication, fulfilling remote data transmitting together with “ECW-AL1” .

(8) Adopting strong inductive magnet, improving the anti-interference capability of the system to the utmost.

(9) Each set has passed strictly aging treatment to assure reliable operation.

(10) The system is based mathematical equations and scientific calculation, correcting inspection error automatically.

(11) On-site adjustment is easy, either by autotuning or by manual displacement setting.

(12) The independent development of the programmable output signal control method can be used for all kinds of traction elevator with moveable car platform.

19、Technical specifications:

1.	Application	Being applicable to all moveable car platform elevators, with an auto inspection range of $(2.00\text{mm} \leq \text{car platform movement} \leq 10.00\text{mm})$; manual setting displacement range $2.5 \sim 9.9\text{mm}$ (relate to parameter PD)	
2.	Sensitivity	Elevator rated load/200 (With the rated load of 1T, it is 5.0Kg)	
3.	System Error	$\leq 1.5\%$ ($5 \sim 40^\circ\text{C}$)	In the whole temperature range $\leq 3.0\%$
4.	Non-Linearity	$\leq 1.0\%$	

Technical File of the EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

5.	Output Mode:	Solid-state Relay	Programmable universal signal	①3/5 channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, overload (customer may set the changing range freely). ②Each channel can be programmed as dynamic Close or Open contact. ③Contact Capacity:DC/AC 32V/15mA.
		Elevator load changes from “no load~ rated load”, analog quantity: 0~10V linearly changing Remote digital communication, with the cooperation of “ECW-AL1” to relies datum remote transfer.		
6.	Storage Temp.	-25~75℃		
7.	Ambient Temperature:	-20~55℃		
8.	Relative Humidity:	20%~99%RH		
9.	Reaction Time	≤0.25 Second		
10.	Power Supply:	AC/DC 24(±10%)V / 150mA		
11.	Installation Place:	Moveable car platform of elevator		
12.	Overall Size:	45×45×90 mm ³		

❖*: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.

Promise





- (1)If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with) 。
- (2)For any requirement of special functions, make it out by mail.
- (3)Any system abnormality in adjustment or operation, please contact our company directly.

Others

EWD-H-XJ3 Intelligent Elevator Load Weighing Device [User's Guide]

1. Accessory Instruction Manual 1 copy Fixing Screw set 2 sets
Inductive magnet [20×20× 1 piece
4mm³]

3. address
book:

 After-sales service: (029)8841 6613	 7D, Block A, Olympic Building, 8th Chang An North Road, Xi'an
 Technical guidance: 180926397 50	 710068